



Dunlop offers an unrivalled range of top quality, ceramic tile fixing products. Using the finest raw materials, our products guarantee the outstanding performance demanded by today's market. With easy-to-follow instructions and illustrations, tiling has never been so simple.

High performance adhesives & sealants – it's what you have come to expect from Dunlop!

Stockist:

For advice ring the Dunlop Technical Hotline 01782 591120.  
Building Adhesives Limited, Longton Road, Trentham, Stoke-on-Trent ST4 8JB

**DUNLOP**  
HIGH PERFORMANCE ADHESIVES & SEALANTS  
www.building-adhesives.com

# THE RIGHT CHOICE FOR TILING bathrooms

## Get it right first time with Dunlop.

The area most commonly tiled in the home is the bathroom – waterproof, hygienic and easy to clean, a tiled surface is ideal in this area. Choosing the right adhesive and grout is vital too – inside this leaflet you will find a helpful illustrated guide. Here are the basics:

- Tiling onto plaster or plasterboard walls

Dry areas:

**Dunlop Ceramic Wall Tile Adhesive**  
and **Dunlop Wall Grout**  
or **Dunlop Fix 'n' Grout**

Shower and bath areas:

**Dunlop Waterproof Ceramic Wall Tile Adhesive**  
and **Dunlop Ready-Mixed Grout**  
or **Dunlop Fix 'n' Grout**

- Tiling onto existing ceramic tiles

**Dunlop Waterproof Ceramic Wall Tile Adhesive**  
and **Dunlop Ready-Mixed Grout**  
or **Dunlop Fix 'n' Grout**

- Grouting a power-shower enclosure

**Dunlop Epoxy Worktop and Shower Grout**

**DUNLOP**

# THE RIGHT CHOICE FOR TILING

Walls should be flat, clean, dry and in a firm, sound condition. Note that typical background surfaces, such as plaster or plasterboard are water sensitive. If the plaster has a dusty appearance wipe down with a damp cloth and prime with **Dunlop Universal Bonding Agent**. Emulsion painted walls should be deeply scored prior to tiling. Use **Dunlop Ceramic Wall Tile Adhesive** on dry areas.



Remember to use **Dunlop Bath & Shower Silicone Sealant** in corners and junctions with other backgrounds, for example baths, basins and vanity tops as shown by the yellow key.

In shower and bath areas, ensure tiles are fixed in a solid bed of adhesive. Use **Dunlop Waterproof Ceramic Wall Tile Adhesive**.

In wet areas use a waterproof grout such as **Dunlop Ready Mixed Grout**. In other areas use **Dunlop Wall Grout**. Please note in power shower areas use an epoxy grout such as **Dunlop Worktop & Shower Grout**.

When tiling onto existing ceramic tiling, allow three days before grouting.

Ensure adhesive and grout is thoroughly dry before using the newly tiled area.

Remember, timber bath sides are prone to movement. Use **Dunlop Waterproof Ceramic Wall Tile Adhesive** and **Dunlop Wall Grout** mixed with **Dunlop Flexible Additive**.

Ceramic tiles are ideal for bathroom floors; waterproof, hygienic and easy to clean they are the perfect permanent solution. Pick up our Floors leaflet for more information.

For more information on tiling in shower areas pick up our Showers leaflet.

## CHECKLIST

- Tiles
- Bonding Agent
- Adhesive
- Grout
- Silicone Sealant
- Tile Trim

## TOOLS AND EQUIPMENT

- Wall Tile Spacers (2 or 3mm)
- Spirit Level
- Tile Cutter
- Tile Nippers
- Tile Saw
- Tile File
- Notched Trowel
- Grout Squeegee/Float
- Sponge
- Sealant Gun
- Plastic Gloves

**Important:** Full instructions for surface preparation and product usage appear on all Dunlop packaging. To make the job easy and worry-free, please ensure you follow them.